

Connection of the solenoid valve for DN125 with air pressure

The operating pressure should lie between 3,5 - 6,0 bar.

Operation with air pressure:

The valves switch faster with air than with water.

Use the silencer supplied with the unit

Installation of the DN125/d140

Included is

1 x 3/2-way solenoid valve (230 V) C Function ON

1 x 3/2-way solenoid valve (230 V) D Function OFF

